https://pchub.com/acer-extensa-5420-series-indicater-board-switch-button-cover-604t308003-p55018

Acer Extensa 5420 Series Indicater Board Switch / Button Cover 60.4T308.003

Model / GTIN	Extensa 5420 Series
Item Condition	Used
Part Description	Cover For Power Button and LED Indicator Board
Part Number	60.4T308.003, 24.T309.XXX, 42.4T309.003
Warranty	1 Month(s)