https://pchub.com/packard-bell-easynote-w3240-indicater-board-switch-button-cover-340687400006-p60129

Packard Bell EasyNote W3240 Indicater Board Switch / Button Cover 340687400006

Model / GTIN	EasyNote W3240
Item Condition	Used
Part Description	Cover For Power Button Board
Part Number	340687400006, 340687400030
Warranty	1 Month(s)