https://pchub.com/dell-xps-m140-indicater-board-switch-button-cover-0ff279-p73499

# Dell XPS M140 Indicater Board Switch / Button Cover 0FF279

| | |
|---|---|
| Model / GTIN | XPS M140 |
| Item Condition | Used |
| Part Description | Indicater Board Switch / Button Cover |
| Part Number | DP/N: 0FF279, FF279, 60.4C433.001, 42.4C411.001 |
| Warranty | 1 Month(s) |
| Info 3 | 42.4C411.XXX |